



Pelco Spectra III

Set camera for Pelco "D" Protocol.

Sennetech converter SCT-CRX-Pelco-Pelco

Use Pelco "P" Protocol at 4800 baud.

Contacting the vendors

For Pelco products documentation and specifications, call at 800-289-9800 or visit www.pelco.com

For Sennetech products documentation and specifications, call 1-517-675-1150, or visit www.sennetech.net

Programming

Before installing the data units, configure them using a PC and SDRLink™ or TrangoLink™ software. The protocol should be set to RS-422/485, 4800 baud; the data rate needs to match that of your Pelco equipment and must be the same for both transmitter and receiver. For installations using Eagle PLUS or Falcon PLUS units for data, they must be fitted with the LC485/422 card. Software downloads are available at www.trangobroadband.com/infobase/programming_software.shtml